

FIG. 1




FIG.2




FIG.3





FIG.4



20020301-000001

Figure 1 is a schematic diagram of a printer control panel. The panel is divided into several sections. On the left, there are three large buttons labeled 'S2', 'S4', and 'S9'. To their right, there are controls for 'ORDINARY PRINTS', including 'SIZE' (L, M, B) and 'QUANTITY' (1, 2, 3) for each size. Below these are 'DELETE' and 'DATA SIZE 1800KB' buttons. On the right side, there are 'QUANTITIES' for 'L: 3', '2L: 0', 'HV: 0', 'P: 0', and 'A4: 0'. At the bottom, there are 'ORDINARY PRINTS' and 'POSTCARD' buttons. On the far right, there is a 'USER INFORMATION' section with fields for 'NAME', 'ADDRESS', 'PHONE NUMBER', 'FAX NUMBER', 'E-MAIL', and 'ADDRESS', each with a corresponding input field. Below this is a 'CHANGE' button. At the bottom right, there are three oval buttons: 'ORDER VIA DATA', 'ORDER VIA INTERNET', and 'CANCEL'. Various reference numerals (41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 62) are placed around the panel to identify specific components.

FIG. 6




FIG.7





FIG. 8



10067125.030102

FIG. 9






FIG. 10

